Preventive Maintenance Schedule for CNC Lathe (Model: ProMax-3500)

This schedule is designed to maximize uptime, extend equipment lifespan, and preemptively address issues related to tool wear, coolant performance, electrical stability, and mechanical strain.

Daily Tasks (Total Estimated Time: ~25-30 minutes)

1. Pre-Shift Inspection & Cleaning (10 minutes):

o Tasks:

- Visually inspect the machine for any signs of damage or misalignment.
- Remove debris, chips, and dust from the work area and machine surfaces.

Importance:

 Prevents buildup that can interfere with moving parts and ensures a clean environment for optimal operation.

2. Coolant & Lubricant Check (7 minutes):

o Tasks:

- Verify coolant levels, clarity, and temperature.
- Check oil levels and ensure lubrication points are functioning.

Importance:

 Maintains proper thermal management and reduces friction, preventing overheating and mechanical wear.

3. Tool and Fixture Quick Review (5 minutes):

Tasks:

 Conduct a brief visual check of cutting tools and fixtures for any obvious signs of wear or damage.

o Importance:

 Early detection of tool degradation helps avoid quality issues and unexpected downtime.

4. System Diagnostics Review (3 minutes):

o Tasks:

• Check the control panel for any alerts or error codes, and verify sensor readings (e.g., temperature, vibration).

Importance:

 Ensures that any minor anomalies are promptly addressed before escalating into major issues.

Weekly Tasks (Total Estimated Time: ~1.5-2 hours)

1. Comprehensive Mechanical Inspection (30 minutes):

○ Tasks:

- Inspect key mechanical components such as bearings, belts, and drive assemblies for wear or misalignment.
- Look for loose fasteners and signs of abnormal vibrations.

Importance:

 Detects early mechanical degradation to prevent unexpected breakdowns and maintain precision.

2. Detailed Coolant System Maintenance (25 minutes):

Tasks:

- Clean coolant filters and flush lines if discoloration or debris is present.
- Inspect the coolant pump and reservoir for proper function.

Importance:

 Ensures efficient heat dissipation and minimizes the risk of overheating and associated damage.

3. Lubrication System Deep Check (20 minutes):

o Tasks:

- Clean and inspect lubrication channels; re-lubricate components as needed.
- Verify that automatic lubrication systems are delivering the proper amount of oil.

Importance:

 Reduces friction and wear on moving parts, ensuring smooth operation and prolonging component life.

4. Sensor Calibration & Log Review (15 minutes):

o Tasks:

- Verify and recalibrate sensors (temperature, vibration, load) if necessary.
- Review system logs to identify any recurring issues.

Importance:

 Accurate sensor readings are crucial for early detection of problems and maintaining overall machine health.

5. Backup & Software Check (10 minutes):

Tasks:

 Back up CNC control software settings and review any recent firmware updates or alerts.

Importance:

 Keeps the control system updated and ensures quick recovery in case of software issues.

Monthly Tasks (Total Estimated Time: ~3-4 hours)

1. Full Mechanical & Electrical Overhaul (1 hour):

o Tasks:

- Perform a thorough inspection of all mechanical components, including gears, couplings, and electrical connections.
- Tighten or replace any worn or loose parts.

Importance:

 A comprehensive check minimizes the risk of unexpected failures by addressing wear before it impacts performance.

2. Deep Coolant System Cleaning & Replacement (45 minutes):

o Tasks:

 Drain and clean the coolant reservoir, replace filters, and inspect coolant hoses.

Importance:

 Prevents clogging and ensures that the cooling system maintains optimal efficiency under high-load conditions.

3. Complete Lubrication System Servicing (30 minutes):

o Tasks:

 Clean lubrication reservoirs, replace lubricants as recommended, and check for leaks in the system.

Importance:

 Consistent lubrication is key to reducing friction-related wear and avoiding mechanical overstrain.

4. System Performance Test & Calibration (30 minutes):

o Tasks:

 Run a full diagnostic test cycle, verifying that all operational parameters (spindle speed, feed rate, temperature, vibration) are within optimal ranges.

Importance:

 Validates the overall health of the machine and ensures that all adjustments made during maintenance are effective.

5. Documentation & Preventive Parts Replacement (15-30 minutes):

Tasks:

- Update maintenance logs with observations, sensor readings, and any replaced parts.
- Proactively replace consumable items (e.g., drive belts, seals) as per manufacturer recommendations.

Importance:

 Keeping detailed records supports trend analysis and proactive scheduling of future maintenance tasks, reducing unplanned downtime.